

BEST PRACTICES



DRYING Before Bagging

We recommend a 10-14 day dry at 60°F & 60% RH. Before filling your bags, your flower should measure ~10-12% moisture (using a moisture meter), or 0.55-0.58aW (using a water activity meter).



CURING

Place flower into bags, leaving ~25% of the bag "empty", creating the headspace that will power our technology. No need to "burp" your bags - simply fill and allow to cure.



SEALING

For curing and product storage, gently twist the bag closed as close to the top opening as possible, leaving headspace above the flower. Be sure not to compress your material or push out excess air. Close your bag with a loosely tied knot, ziptie, or bag clip.



STORING

Store in a cool, dark room around 60° and 60% RH, and enjoy a hands-free cure, better terpene preservation, and maximum weight retention.

